




© THIS DRAWING IS THE PROPERTY OF PACIFIC BUILD SUPPLY LTD AND MUST NOT BE COPIED WITHOUT PERMISSION



**NOTE:** FOR SLOPING SOFFITS, ENSURE RAILS & ADHESIVE LINES RUN IN THE SAME DIRECTION AS SLOPE. WILL NOT REQUIRE ALL 4 EDGES TO BE ADHERE BUT MAY REQUIRE MORE LSAs. READ IN CONJUNCTION WITH DETAILS PXS.2.07-09.

**NOTE:** FOR **SWISSPEARL** SOFFIT PANELS, MAX. FRAMING / RAILS AT 400mm CENTRES.

<p><b>XpressClad Soffits - Adhesive Fixed Decorative Soffit</b></p> <p>Reflected Ceiling Plan - Large Area - Cavity Rail &amp; Adhesive Layout and Panel / Fixing Layout - Parallel Orientation</p>		<p>Scale</p> <p>1 : 20</p>	<p>Date</p> <p>17/07/20</p>
<p><b>pacific build supply ltd</b></p>		<p>www.pacbld.com</p> <p>0800 2255 727</p>	<p>Dwg. No.</p> <p><b>PXS.1.02</b></p>